

Baofeng UV 5R			<b>PUSH AND HOLD MON FOR LIGHT. POLICE AND FIRE TURN # 24/25 OFF SO YOU DO NOT TRANSMIT</b>
SIMPLEX	SETTING	DESCRIPTION	
0	SQL	1	SETS SQUELCH
1	STEP	5	CHANGES FREQUENCY STEP IN VFO if to 4th pl then 2.5 or 12.5
2	TXP	high	SETS TRANSMIT POWER
3	SAVE	off	0=off
4	VOX	off	VOICE OPERATED KEYING/TRANSMIT
5	WN	Wide	WIDE OR NARROW BANDWIDTH
6	ABR	CHOOSE	BACKLIGHT TIMER
7	TDR	ON OR OFF	MONITORS 2 FREQUENCIES AT SAME TIME OR JUST 1
8	BEEP	CHOOSE	KEY SOUND
9	TOT	120	TRNS T/O TIMER/ FOR ACCIDENTAL LONG KEY OF PTT/ <b>SET TO LESS THAN 15 WHL PRGMG W/ CABLE</b>
10	R-DCS	OFF/PRIVACY	SIMPLEX RECEIVE SECURITY CODE
11	R-CTCS	OFF	REPEATER RECEIVE CODE
12	T-DCS	OFF/PRIVACY	SIMPLEX TRANSMIT SECURITY CODE
13	T-CTCS	OFF	REPEATER TRANSMIT CODE
14	VOICE	ENG	CHOOSES LANGUAGE
15	ANI-ID		DISABLE FUNCTION CAN NOT CHANGE (CHIRP ONLY)
16	DTMFST		DISABLE FUNCTION CAN NOT CHANGE (CHIRP ONLY)
17	S-CODE	1	OFF
18	SC-REV	TO	SAVE CHANNEL REVERSE
19	PTT-ID	OFF	
20	PTT-LT	OFF	
21	MDF-A	CHOOSE	DISPLAY NAME, FREQ OR CHANNEL. NAME ADDED WITH CHIRP
22	MDF-B	CHOOSE	DISPLAY NAME, FREQ OR CHANNEL. NAME ADDED WITH CHIRP
23	BCL	OFF	BUSY CHANNEL LOCK OUT ..SKIPS BUSY CHANNELS WHEN SCANNING
24	AUTOLK	OFF	PRESS AND HOLD # TO LOCK / UNLOCK KEYS
25	SFT-D	OFF	SET FREQ TRANSMIT + OR -
26	OFFSET	OFF	SETS FREQUENCY OFFSET FOR REPEATERS
27	MEM-CH		CHOOSE MEM CHANNEL (MUST BE DELETED 1ST)
28	DEL-CH		DELETES MEMORY CHANNEL
29	WT-LED	CHOOSE	WAIT LED COLOR
30	RX-LED	CHOOSE	RECEIVE REC.LED COLOR
31	TX-LED	CHOOSE	TRNSMIT LED COLOR
32	AL-MOD	TONE	HOLD CALL BUTTON TO ALARM AND TRANSMIT FOR EMERGENCY
33	BAND	AUTO SELECTS	SELECTS BAND
34	TDR-AB	A	PRIORITY CHANNEL ?
35	STE	OFF	SQUELCH TALK ELIMINATOR... ONLY FOR SETTING UP DUPLEX BETWEEN RADIOS
36	RP-STE	OFF	SQUELCH TALK ELIMINATOR... ONLY FOR SETTING UP DUPLEX BETWEEN RADIOS
37	RPD-RL	OFF	SQUELCH TALK ELIMINATOR... ONLY FOR SETTING UP DUPLEX BETWEEN RADIOS
38	PONMSG	FULL OR MSG	POWER ON MESSAGE
39	ROGER	CHOOSE	TONE SENT AFTER KEYING
40	RESET		RESETS TO FACTORY SETTINGS

Baofeng UV 5R			
REPEATER	SETTING	DESCRIPTION	
0	SQL	1	SETS SQUELCH
1	STEP	5	CHANGES FREQUENCY STEP IN VFO if to 4th pl then 2.5 or 12.5
2	TXP	high	SETS TRANSMIT POWER
3	SAVE	off	0=off
4	VOX	off	VOICE OPERATED KEYING/TRANSMIT
5	WN	Wide	WIDE OR NARROW BANDWIDTH
6	ABR	CHOOSE	BACKLIGHT TIMER
7	TDR	ON OR OFF	MONITORS 2 FREQUENCIES AT SAME TIME OR JUST 1
8	BEEP	CHOOSE	KEY SOUND
9	TOT	120	TRNS T/O TIMER/ FOR ACCIDENTAL LONG KEY OF PTT/ <b>SET TO LESS THAN 15 WHL PRGMG W/ CABLE</b>
10	R-DCS	OFF	SIMPLEX RECEIVE SECURITY CODE
11	R-CTCS	OFF	REPEATER RECEIVE CODE
12	T-DCS	OFF	SIMPLEX TRANSMIT SECURITY CODE
13	<b>T-CTCS</b>	<b>ENTER PI FREQ</b>	<b>REPEATER TRANSMIT CODE</b>
14	VOICE	ENG	CHOOSES LANGUAGE
15	ANI-ID		DISABLE FUNCTION CAN NOT CHANGE (CHIRP ONLY)
16	DTMFST		DISABLE FUNCTION CAN NOT CHANGE (CHIRP ONLY)
17	S-CODE	1	OFF
18	SC-REV	TO	SAVE CHANNEL REVERSE
19	PTT-ID	OFF	
20	PTT-LT	OFF	
21	MDF-A	CHOOSE	DISPLAY NAME, FREQ OR CHANNEL. NAME ADDED WITH CHIRP
22	MDF-B	CHOOSE	DISPLAY NAME, FREQ OR CHANNEL. NAME ADDED WITH CHIRP
23	BCL	OFF	BUSY CHANNEL LOCK OUT ..SKIPS BUSY CHANNELS WHEN SCANNING
24	AUTOLK	OFF	PRESS AND HOLD # TO LOCK / UNLOCK KEYS
25	<b>SFT-D</b>	<b>CHOOSE +/-</b>	<b>SET FREQ TRANSMIT + OR -</b>
26	<b>OFFSET</b>	<b>CHOOSE</b>	<b>SETS FREQUENCY OFFSET FOR REPEATERS .600mH FOR 2M / 5.0 FOR 70CM</b>
27	MEM-CH		CHOOSE MEM CHANNEL (MUST BE DELETED 1ST)
28	DEL-CH		DELETES MEMORY CHANNEL
29	WT-LED	CHOOSE	WAIT LED COLOR
30	RX-LED	CHOOSE	RECEIVE REC.LED COLOR
31	TX-LED	CHOOSE	TRNSMIT LED COLOR
32	AL-MOD	tone	HOLD CALL BUTTON TO ALARM AND TRANSMIT FOR EMERGENCY
33	BAND	AUTO SELECTS	SELECTS BAND
34	TDR-AB	A	PRIORITY CHANNEL ?
35	STE	OFF	SQUELCH TALK ELIMINATOR... ONLY FOR SETTING UP DUPLEX BETWEEN RADIOS
36	RP-STE	OFF	SQUELCH TALK ELIMINATOR... ONLY FOR SETTING UP DUPLEX BETWEEN RADIOS
37	RPD-RL	OFF	SQUELCH TALK ELIMINATOR... ONLY FOR SETTING UP DUPLEX BETWEEN RADIOS
38	PONMSG	FULL OR MSG	POWER ON MESSAGE
39	ROGER	CHOOSE	tone SENT AFTER KEYING
40	RESET		RESETS TO FACTORY SETTINGS